


Select Bike Profile

- \odot Long Press DATA2/BIKE button to enter bike profile selection.
- ② Short press DATA1/MENU to select Bike.



Select DATA1


Select cycling data



Select DATA2

Select more cycling data

- Short Pressing DATA2/BIKE can switch lower part LCD data.
- Data displayed on lower part LCD
 Bike ODO/Clock → Altitude+Slope/Trip time →
 Calories+Temperature/Trip time → Total climb/Trip time
 → Instant power/Balance(L & R)/Trip time.
- Power data is displayed only when power meter is installed.



Lap

Split Laps and Mark position

- Short Press LAP/R-START will split record into laps. Last lap data is displayed on LCD (Lap Heart Rate, Lap Cadence Lap Speed, Lap count, Lap distance, and Lap time).
- Position of lap point is marked on recorded track.



RESTART

Restart a new record

- Long Press LAP/R-START can start count down of restarting a new record.
- At end of count down, new record is started and previous record will be saved.



MENU

Setting E7 cycling computer

- Long Press DATA1/MENU will enter device setting MENU
- In MENU mode, follow screen to select your settings



☐ Icon indicates you could press DATA2/BIKE key to enter sub-menu or change setting



TOUR·X PLOVA.com

Outdoor community portal

- Upload, review, analysis, & share your activity records.
- Support Windows and Mac.
- Tagging photos to activity record
- Upload activities record, view GPS track data on Map
- Share record via Facebook, Twitter or web link.
- Review detail of activity data by graphics and charts



